

SOFT ROLL UP COVER FITTING INSTRUCTION

STEP 1: Insert 2 hooks into each rail , then place the rails on both sides and make sure that the ends of the rails close to the tailgate



STEP 2: Place the tonneau cover horizontally on the tail box close to the edge of the cab side, then insert the connection lip on both sides of the tonneau cover into the ends of the rails.



STEP 3: Move 4 adjusting hooks to the proper positions at both ends of the tracks,



STEP 4: Use a wrench to tighten the screws on the top of the adjustment hooks.



STEP 5: Place two crossbars horizontally into the alu rail. No.1 cross bar (longer) shall be insert in the front and No.2 cross bar (may shorter) shall be insert in the rear.



STEP 6: Pull out the wire to make the rod back inside, then insert the extrusion lip into the side rail gutter. if the wire can't pull out, pls push the pressure on the two ends and pull out the wire to make sure rod back inside. Close the cover and tail gate.



STEP 7: insert the two side rubber strip into alu rails gutter and Done



Attention !!

1. Pls pull vertically the wire from up to down to make the rod back when you open the cover. If it is hard to open cover, pls pressure down soft cover in the middle and pull the wire vertically at the same time make sure the rod is pulled back.
2. The alu part can be damage when the rod don't pull back completely by strong pressure too open
3. Pls make sure two side rails are fixed tightly after using sometime and fix with rear alu lip in the proper position before open and close